

# SPART



**PUMP SET RACK** 

GT1500

## **SAFETY PRECAUTION**

## **Safety First**


Regardless of how enthusiastic you may be about getting on your equipment and exercising, take the time to ensure that your safety is not jeopardized. A moment's lack of attention can result in an accident, as can failure to observe certain simple safety precautions.

- 1. Assemble the equipment according to the assembly instructions and only use the individual parts enclosed for assembly of the equipment and which are listed in the parts list as being specifically for this equipment. Before you start assembly, check against the delivery to make sure that everything has been delivered and check against the packing list to make sure all parts have been enclose.
- 2. Read, study and understand the Owner's Manual and all the warning labels on this product. Furthermore, it is recommended to familiarize yourself and others with the proper operation and workout recommendations for this product prior to use. Some of this information can be obtained in this owner's Manual, as-well-as from your local retailer.
- 3. It is imperative that you retain this Owner's Manual and be sure all warning labels are legible and intact. Replacements Owner's Manual and labels are available from your local retailer.
- 4. It is recommended that another person assist you with the assembly this unit.
- 5. Consult with your physician before beginning any exercise program. It is recommended that you undergo a complete physical examination.
- 6. Use proper discretion when children are present.
- 7. Frayed or worn cables can be dangerous and may cause injury. Periodically check these cables for any indication of wear.
- 8. Keep hands, limbs, loose clothing and long hair well out of the way of moving parts.
- 9. Do not attempt to lift more weight than you can control safely.
- 10. Work within you recommended exercise level. DO NOT work to exhaustion. If you feel any pain or discomfort, stop your workout immediately.
- 11. Inspect the machine for any sign of wear on parts, hardware becoming loose or cracks on welds. If a problem is found do not use or allow the machine to be used until the defective part is repaired or replaced.
- 12. DO NOT place any sharp objects around the machine.

# **EXPLODED DRAWING** 15 18 - 17 10 11 o 19 16 13

	0			0	
NUMBER	DESCRIPTION	QUANTITY	NUMBER	DESCRIPTION	QUANTITY
1	MAIN FRAME	2	11	ROUND END CAP	24
2	TOP JOINT TUBE	1	12	BOLT M10*60	2
3	DOWN JOINT TUBE	1	13	BOLT M10*100	24
4	SUPPORT	4	14	BOLT M12*20	20
5	вох	1	15	BOLT M12*55	2
6	PLATE BAR	20	16	WASHER 10	4
7	SEPTAL POLE	2	17	BEDN WASHER 10	24
8	RUBBER PAD	4	18	WASHER 12	22
9	ELLIPTICAL END CAP	2	19	LOCK NUT M10	2
10	RUBBER RING	20			

### www.zunfit.com





#### **ITALY OFFICE**

Zun Srl via Mammarella snc 66100 Chieti Scalo (CH),Italy Email: info@zunfit.com Phone: +39 0871 551762

#### **CHINA OFFICE**

Zunone 83# South Tongfu Road, Nantong Jiangsu China Email: simon@zunone.cn Phone: +0086-13901602295